
ADT672 Communicationprotocol

(1) Instructionformat

① Data sendingformat:

A: X: Kn_{nnn}: C0: C1: C2: C3: C4+EOS (end of symbol)

A: 1 byte, the instrument's communicationaddress

X: 1 byte, only for W (write) or R(read)

K: 1 byte, M (measure), F (File), O(others)

nn_{nnn}: 2-5 bytes, the items operated by K in instruction

C0: C1: C2: C3: C4: Parameter, please refer the specified instruction

introduction Eos : 0x0(hex)

② Data returningformat :

A: X: Kn_{nnn}: C0: C1: C2: C3: C4+ Eos, hereinto:

A: Instrument communicationaddress

X: E or F, E is error info of this frame dates, F is feedback

info Kn_{nnn}: It is same as the instruction from uppermachine

C0: C1: C2: C3: C4: Feedback data or error info

Eos:0x0(hex)

③ The communication setting of serialport

A(address) : the range is 1 ~ 112, factory default setting is 1

Baud rate: 1200、2400、4800 and 9600 is selected, the factory default setting is

9600 Data bit length: 8bits

Stop bit: 2 bits

Parity digit:N/A

Data flow control:N/A



(2) Instructiondetails

Instructions								FunctionIntroduction	Correct returnvalue	
A	X	Knnnn	C0	C1	C2	C3	C4	Eos		
Address	R	OVER	-	-	-	-	-	0X00	Read software versionNo.	A:F:OVER:version No.+Eos
	R	OTYPE	-	-	-	-	-		Read instrument ModeNo.	A:F:OVOK:Mode No.+Eos
	R	OCTYPE	-	-	-	-	-		Read serialnumber	A:F:OCODE:serial No. OK+Eos
	R	OPRDA	-	-	-	-	-		Read productiondate	A:F:OPRDA:production date OK+Eos
	W	OBLAC	0(close) 1(open)	-	-	-	-		Open/closebacklight	A:F:OBLAC:OK+Eos
	W	OBEEP	0(close) 1(open)	-	-	-	-		Open/closebuzzer	A:F:OBEEP:OK+Eos
	W	OKEY	0(close) 1(open)	-	-	-	-		Open/closekeypad	A:F:OKEY:OK+Eos
	R	OTIME	-	-	-	-	-		Read clock'stime	A:F:OTIME:H: M: S:+Eos
	W	OTIME	hour	minute	second	-	-		Set up clock'sdate	A:F:OTIME:OK+Eos
	R	ODATE	-	-	-	-	-		Read clock'sdate	A:F:ODATE:Y:M:D+Eos
	W	ODATE	year	month	day	-	-		Write clock'sdate	A:F:ODATE:OK+Eos
	R	OBATV	-	-	-	-	-		Read battery's totalvoltage	A:F:OBATV:total voltage+Eos
	R	EXMENU	-	-	-	-	-		Read menu status (0:N/A;1:Available)	A:F:EXMENU:menu status+Eos
	W	EXMENU	-	-	-	-	-		Quit menustatus	A:F:EXMENU:OK+Eos
	R	OADDR	-	-	-	-	-		Read series port'sadd(1-121)	A:F:OADDR:address+Eos
	W	OADDR	address	-	-	-	-		Set series port'sadd(1-121)	A:F:OADDR:OK+Eos
	W	OBAUD	Baudrate	-	-	-	-		1200 , 2400 , 4800 , 9600	A:F:OBAUD:OK+Eos
	W	O24V	0(close) 1(open)	-	-	-	-		Open/close 24Voutput	A:F:O24V:OK+Eos
	W	O24VT	1 (10minute) 2 (30minute) 3 (60minute) 4 (full-open)	-	-	-	-		Set up working time of24V	A:F:O24V:OK+Eos

Instructions									FunctionIntroduction	Correct returnvalue	
A	X	Knnnn	C0	C1	C2	C3	C4	Eos			
Address	W	OBIT	P(pressure) E(electricity) A(all)	0 (5digits) 1 (6digits)	-	-	-	-	0X00	Switch the displayresolution	A:F:OBIT:OK+Eos
	W	OCONT	0(close) 1(open)	-	-	-	-	-		Set data sendingcontinuously	A:F:OCONT:OK+Eos
	R	ORAN	-	-	-	-	-	-		Read pressure range andtype (0: gauge or absolute, 1: differential)	A:F:ORAN:lower limit: high limit: pressure unit+Eos
	R	MRMD	-	-	-	-	-	-		Read current pressurevalue.	A:F:MRMD:P value: unit+Eos
	R	OUINF	-	-	-	-	-	-		Read the selected pressure unit info code, refer toApp.(5)	A:F:OUINF:unit info code+Eos
	W	OUNIT	ShorteningUnit	-	-	-	-	-		Switch pressure unit, refer App.4	A:F:OUNIT:OK+Eos
	W	OZERO	-	-	-	-	-	-		Pressure tozero	A:F:OZERO:OK+Eos
	W	MZERO	P (Pressure) I (Current) V(Voltage)	-	-	-	-	-		Cancel the previouszeroing	A:F:MZERO:OK+Eos
	R	OPEAK	-	-	-	-	-	-		Read peakpressure	A:F:OPEAK:High peak value:Lower peak value :unit +Eos
	W	OPKZE	-	-	-	-	-	-		Clear peak pressure to presentvalue.	A:F:OPKZE:OK+Eos
	W	MRATE	0(low speed) 1(highspeed)	-	-	-	-	-		Adjust pressuresresponsetime	A:F:MRATE:OK+Eos
	W	MCONE	I (current) V(voltage) T(temperature) S(switch) L(count-down) H(HART)	-	-	-	-	-		Switch measureitems	A:F:MCONE:OK+Eos



Instructions									FunctionIntroduction	Correct returnvalue
A	X	Knxxx	C0	C1	C2	C3	C4	Eos		
Address	R	MVAL	-	-	-	-	-	-	Read measuring electricitydate	Current, voltage, temperature A:F:MVAL:value: mA /V/°C+Eos Switch A:F:MVAL:ON/OFF:SW+Eos Count down A:F:MVAL:START: Start pressure: END:final pressure: hour: minute: second+Eos Return HART function, please refer(8)
	W	OVALZ	-	-	-	-	-	-	Electricity zeroing is only effective for I&V	A:F:OVALZ:OK+Eos
	R	OTEMP	-	-	-	-	-	-	Read environmentTEMP.	A:F:OTEMP:temperature:°C+Eos
	W	MSWI	0 (notrigger) 1 (off→on) 2 (on→off) 3(off→on→off) 4(on→off→on)	-	-	-	-	-	Set up pressure switch's workingtype.	A:F:MSWI : OK+Eos
	W	MSTIO	-	-	-	-	-	-	Unlock the triggerswitch	A:F:MSTIO:OK+Eos
	R	RSWI	-	-	-	-	-	-	Read switch's triggervalue	A:F:RSWI:pressure value: unit: switch on/off status: trigger
	W	MLEKT	hour	minute	second	-	-	-	Set up leak huntingtime	A:F:MLEKT:OK+Eos
	W	HARTSW	0-8 HARTfunction	-	-	-	-	-	Switch HART function item0-8	A:F:HARTSW:OK+Eos
	W	FIXAO	4-20mA currentvalue	-	-	-	-	-	Set transmitter outputting the fixed current. It is canceled if current is0.	A:F:FIXAO:OK+Eos
	W	AOCAIB	0 (4mA) 1 (20mA)	Current calibration	-	-	-	-	Calibrate the transmitter's loopcurrent	A:F:AOCAIB:OK+Eos
	W	PVCAIB	0 (ZERO) 1 (SPAN)	-	-	-	-	-	Calibrate the high and lower limit of transmitter	A:F:PVCAIB:OK+Eos
	W	PVTRAN	Highlimit	Lowerlimit	Unit	-	-	-	Transfer transmitterrange	A:F:PVTTRAN:OK+Eos
	W	DAMPING	Dampvalue	-	-	-	-	-	Set transmitter dampvalue	A:F:DAMPING:OK+Eos
	R	HARTSTA	-	-	-	-	-	-	Read HART order implementstatus	A:F:HARTSTA>Status (0/1) +Eos

Instructions									FunctionIntroduction	Correct returnvalue
A	X	Knnnn	C0	C1	C2	C3	C4	Eos		
Address	W	HARTCMD	HART sendingframe	-	-	-	-		0X00	Set up HART's command inrandom
	W	FMODE	0(manual) 1(auto)	0(hour) 1(interval)	0(short) 1(long)	-	-			A:F:FMODE : OK+Eos
	R	FMODE	-	-	-	-	-			Read savemode
	W	FTIME	hour	minute	second	-	-			A:F:FTIME:OK+Eos
	W	FSTART	1 ~ 30	-	-	-	-			A:F:FSTART:OK+Eos
	W	FSAVE	-	-	-	-	-			A:F:FSAVE:OK+Eos
	W	FSTOP	-	-	-	-	-			A:F:FSTOP:OK+Eos
	R	FRDO	Filenumber	-	-	-	-			Read a file'sdata
	W	FDELO	Filenumber	-	-	-	-			Return format refer to(1)
	W	FDELA	-	-	-	-	-			A:F:FDELO:OK+Eos
	W	OCPS	-	-	-	-	-			A:F:FDELA:OK+Eos
	W	OCP	Z(zero) M(middle) F(full)	Standard P at calibrationpoint	-	-	-			Entrance instruction of pressurecalibration
	W	OCPOK	1(save)0(cancel)	-	-	-	-			A:F:OCP:OK+Eos
	W	OCIS	-	-	-	-	-			Input the pressure value and relative calibration point,
	W	OCI	1 / 2/3	Standard I at calibrationpoint	-	-	-			Quit pressurecalibration
	W	OCTOK	1(save)0(cancel)	-	-	-	-			A:F:OCIS:OK+Eos
	W	OCVS	-	-	-	-	-			Input the current value and relative calibration point,
	W	OCV	1 / 2/3	Standard V at calibrationpoint	-	-	-			Quit currentcalibration
	W	OCVOK	1(save)0(cancel)	-	-	-	-			A:F:OCV:OK+Eos
	W	OFALT	P/ I/V	-	-	-	-			Entrance instruction for voltagecalibration
	W	OTAG	NoteNo.(1 ~ 10)	Notecontent 50 byteslongest	-	-	-			A:F:OCVOK:OK+Eos
	R	OTAG	NoteNo.(1 ~ 10)	-	-	-	-			Cancel calibration parameter and write note'sinformation
										A:F:OTAG:OK+Eos
										Read note'sinformation
										A:F:OTAG:Note #:Note info+Eos



(3) The file's transferformat

```
Filename:F01          /* File name*/  
Number:111111         /* the serial No. of second gauge*/  
Minscale:001.000     /* Minimum scale value*/  
Datesum:01           /* the saved points in file*/  
No.0106/07/0310:29:53 /* Point number, save date,time*/  
0.0108MPA           /* Pressure measure value*/  
-0.0000mA            /* Electricity measure value*/
```

(4) Pressure units shorteninglist

Shortening	H ₂ O	HG	PSI	MBAR	BAR	PA	KPA	MPA
Standard	mmH ₂ O	mmHg	psi	mbar	bar	Pa	kPa	MPa

(5) Pressure units infocode

Info code use 1 byte.1: this pressure unit is available; 0:N/A

HG	H ₂ O	PSI	BAR	MBAR	MPA	KPA	PA
MSB	LSB						

(6) The format of automatically datasending

The format length is 32 bytes, and add the Eos 0x0 at the

end. Example: *P 0.0364 MPA*I-0.0001 mA

*P 0.0367 MPA*V-0.0158 V

*P 0.0374 MPA*T32.19 °C

*P 0.0375 MPA*S000000.0 0

*P 0.0397 MPA *L10:00:05

(7) Wrong sequence number explanation

- 1000 Accept outflow from buffer.
- 1001 The instruction is being protected now.
- 1004 Digital character string have non-permitted characters.
- 1005 Pressure unit is irregular.
- 1007 Parameter is wrong.
- 1016 The data can't meet the zeroing requirements.
- 1017 The parameter quantities is not enough.
- 1018 Unsupported instruction.
- 1019 The format of operation password is wrong.
- 1020 r/w Symbol is wrong.
- 1021 The file number is out of range.
- 1023 The shortening pressure unit is wrong.
- 1024 This pressure unit can't use.
- 1025 The series address is out of range 1-112.
- 1026 Baud rate is wrong.
- 1027 The time parameter of 24V open/close is wrong.
- 1029 Parameter is too long.
- 1030 Not contact with HART yet.

(8) HART function's return format

► Function 0: Linked the POLLING successfully

Address: F: MVAL: DEVICE: Manufacture: Equipment type: Equipment
ID Example: 001: F: MVAL: DEVICE: Endress & Hauser: Cerabar M:



W["Q

►Function 1: Display the sensor ranges used by HARTtransmitter.

Address: F: MVAL: SENSOR_RANGE: Lower limit of sensor: Higher limit of sensor: Pressureunit
Switch to function 1,it is returned but not enter into the interface yet (example 1); oppositely, it returns after interface displayed (example2)
Example 1: 001: F: MVAL: SENSOR_RANGE: 0.0000000: 0.0000000:NC
Example 2: 001: F: MVAL: SENSOR_RANGE: -40.000000: 40.000000:KPA

►Function 2: Display and transfer the PV range of transmitter, switch PVunits

Address: F: MVAL: PV_RANGE: Lower limit of PV range: Higher limit of PV range: Pressureunit
Switch to function 2, it returned but not enter in the PV interface yet (example 1); oppositely, it returns after interface displayed (example2)
Example-----001: F: MVAL: PV_RANGE: 0.0000000: 0.0000000: NC
Example-----001: F: MVAL: PV_RANGE: -0.01506382: -0.02472788:KPA

►Function 3: Display and adjust transmitter's dampvalue

Address: F: MVAL: DAMPING: damp value: Unit
(second) Example-----001: F: MVAL: DAMPING: 1.000:s

►Function 4: Simultaneously display the pressure value measured by calibrator andtransmitter.

Address: F: MVAL: PV/MP_VALUE: pressure measured by transmitter:Unit:pressure measured by calibrator:Unit
Switch to function 4, it returned but not enter in the PV/MP interface (example 1); oppositely, it returns after interface displayed (example2)
Example 1-----001: F: MVAL: PV/MP_VALUE: 0.00000: NC: 0.01414:KPA
Example 2-----001: F: MVAL: PV/MP_VALUE: 0.00973: KPA: 0.00984:KPA

-
- ▶ Function 5: Simultaneously display the pressure value measured by calibrator and the current value measured by transmitter
Address: F: MVAL: AO/MP_VALUE: Current value measured by transmitter: Unit: pressure value measured by calibrator: Unit Switch to function 5, it returned but not enter in the AO/MP interface yet (example 1); oppositely, it returns after interface displayed (example2)
Example 1-----001: F: MVAL: AO/MP_VALUE: 0.00000: MA: 0.01088:KPA
Example 1-----001: F: MVAL: AO/MP_VALUE: 4.00000: MA: 0.01012:KPA
 - ▶ Function 6: Simultaneously display the both current value measured by calibrator and transmitter.
Address: F: MVAL: AO/MI_VALUE: Current value measured by transmitter: unit: current value measured by calibrator: unit Example: 001: F: MVAL: AO/MI_VALUE: 4.00000: MA 4.00265:MA
 - ▶ Function 7: Appoint to the fixed current output from transmitter; calibrate the current output from transmitter
Address: F: MVAL: FIXAO/MI_VALUE: Current output from transmitter: unit: current value measured by calibrator: unit Switch to function 7, it returned but not enter in the FIXAO/MI_VALUE yet (example 1); oppositely, it returns after it is displayed (example2)
Example1: 001: F: MVAL: FIXAO/MI_VALUE: 0.00000: MA 4.00255:MA
Example2: 001: F: MVAL: FIXAO/MI_VALUE: 4.00000: MA 4.00249:MA
 - ▶ Function 8: Calibrate the PV ranges of transmitter
Address: F: MVAL: MP_VALUE: The pressure value measured by calibrator:
unit Example: 001: F: MVAL: MP_VALUE: 0.01025:KPA
 - ▶ Function 9: Special calibration mode
Address: F: MVAL: MP/MI_VALUE: Pressure value measured by calibrator: current value measured by calibrator:
unit Example: 001: F: MVAL: MP/MI_VALUE: 0.00346: KPA: 4.00242:MA


